November 2026

Ethernet Adapter

Product description



FDS
TIMING SOLUTIONS

FDS-TIMING, SWITZERLAND

1. Description

The FDS Ethernet Adapter module is designed to enhance the flexibility of your timing setup by allowing any FDS RS-232 device to connect to your LAN network.

2. RS232 Connection

When used with a TBox or DBox, simply connect an XH2.54 seven-wires cable to the auxiliary port. Do not use any power cable as power is supplied directly by the TBox or DBox (!!! TBox battery life will be reduced.)



When used with an MLED, a special XH2.54-to-MR30 data cable is required. An external power supply must also be connected through the power jack.



The default RS-232 settings are 9600 baud, 8 data bits, and 1 stop bit.

3. Ethernet Connection

Below are the default settings for this adapter.
Although these settings can be modified through a web browser by entering the device's IP address, FDS does not recommend doing so. Any changes are made at your own risk.

- **IP address:** Assigned by the router via DHCP
- **Mode:** TCP server
- **Port:** 7000

4. Tutorial videos

- **Presentation:** https://www.youtube.com/watch?v=YQ2oEyZ-GxU

5. Copyright and Declaration

This manual has been compiled with great care, and the information it contains has been thoroughly verified. While the text was accurate at the time of printing, the content may change without notice. FDS accepts no liability for any damage resulting directly or indirectly from errors, omissions, or discrepancies between this manual and the product described.
The sale of products and services covered by this publication is governed by FDS's standard Terms and Conditions of Sale. This manual is provided for informational purposes only and applies to the standard model of the product type specified above.
Trademarks: All hardware and software product names used in this document may be registered trademarks and should be treated accordingly.

FDS-TIMING Sàrl
Rue du Nord 123
2300 La Chaux-De-Fonds
Switzerland
www.fdstiming.com